

REJUVenate®

Ready to Use

One-Step Disinfectant

FOR USE IN SPAS, SALONS & CLINICS

See label on original container or reference sheet for complete directions for use, complete list of pathogenic organisms, and additional information.

KEEP OUT OF REACH OF CHILDREN

Bactericidal, *Virucidal, Pseudomonacidal, Fungicidal, and Tuberculocidal



Meets OSHA Bloodborne Pathogen Standard for *HBV, *HCV & *HIV-1

EPA Reg. No. 74559-1
EPA Est. No. 74559-CAN-1

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

FOR USE AS A ONE-STEP DISINFECTANT PRODUCT:

1. Pre-clean heavily soiled areas.
2. Apply solution by spray, cloth, or disposable wipe to hard, non-porous environmental surfaces.
3. All surfaces must remain wet for 1 minute. Use a 5 minute contact time for Mycobacteria† and a 10 minute contact time for fungi.
4. Allow to air dry.

ALWAYS RINSE CONTAINER AND AIR DRY THOROUGHLY BEFORE REFILLING. THIS CONTAINER SHOULD NOT BE USED WITH ANY OTHER PRODUCT.

HAZARD RATING

HMIS/NFPA	
0	Health
0	Flammability
0	Reactivity

4 = Very High
3 = High
2 = Moderate
1 = Slight
0 = Insignificant

Si no puede leer en inglés, pregunte a su supervisor sobre las instrucciones de uso apropiadas antes de trabajar con este producto. (If you cannot read English, ask your supervisor for the appropriate instructions before handling this product.)

Accelerated Hydrogen Peroxide® and Design are registered trademarks of Diversey Inc. "Accelerated" does not imply increased product efficacy.

Questions?
Visit LearnAboutRejuvenate.com

VHH178 (20/351)

Date Transferred to Secondary Container

Lot # / Expiry Date

For relevant patents, visit: virox.com/patents

S.D.S. available online at LearnAboutRejuvenate.com

**Container refilled by user.
Not for resale**



Manufactured by:

Virox Technologies Inc.
2770 Coventry Road
Oakville, ON Canada L6H 6R1